

# MHM5

## DEVICE NET ABSOLUTE MULTI-TURN ENCODER



### **Features**

MHM510, standard encoder Ø58mm with DeviceNet interface:

- Robust and compact design
- Solid shaft version Ø 10 mm (06 mm available upon request)
- Precision ball bearings with sealing flange
- High temperatures performances –40°C ... +85°C
- Code disc made of unbreakable and durable plastic
- Mechanical memorisation of the number of turns by gears
- Resolution: 13 bits = 8192 steps/turn (max 16 bits)
- Number of Turns: 12 bits = 4096 turns (max 14 bits)
- Polarity inversion and short circuit protection
- Highly integrated circuit in SMD-technology



## **SPECIFICATIONS**

### Mechanical

	Cover: Aluminum
Material	Body: Aluminum
	Shaft: Stainless Steel
May Shaft Loading	Axial: 40 N
Max. Shaft Loading	Radial: 110 N
Shaft Inertia	$\leq$ 30 g.cm <sup>2</sup>
Torque	≤ 3 N.cm
RPM (Continuous Operation)	6 000 tr/min
Shock (EN 60068-2-27)	≤ 100 g (half-sinus, 6 ms)
Shock (EN 60028-2-29)	≤ 10 g (half-sinus, 16ms)
Vibrations (EN 60068-2-6)	≤ 10 g (10Hz 1 000Hz)
Weight	600 g
Operating Temperature	- 40 + 85°C
Storage Temperature	- 40 + 85°C
Humidity	98 % without Condensation
Protection Class (EN 60529)	IP65: cover

Lifetime in 10 <sup>8</sup> Revolutions with F <sub>a</sub> / F <sub>r</sub> (Axial / Radial)		
40 N / 60 N	40 N / 80 N	40 N / 110 N
25	10	4



# Electrical


Interface	Transceiver According ISO/DIS 11898
Transmission Rate	Max 500KBauds
Device Addressing	By Rotary Switches
Power Supply	10 – 30Vdc
Current Consumption	Max. 100mA (24Vdc)
Power Consumption	Max 2,5W
Step Frequency LSB	800 kHz
Accuracy of Division	+ ½ LSB
EMC	EN 61000-6-4 EN 61000-6-2
Electrical Lifetime	> 10 <sup>5</sup> h



## **DIMENSIONS**


All dimensions are in millimeters.

# MHM510-DNET (Connection Cap Included)



Status visualization by 2 LED's at the back of the connection cap

Sta - Green LED	Meaning
Off	No Power Supply
On	Encoder is ready, Boot Up message not sent (no further device on network, wrong baud rate) or encoder in prepared status
On	Boot Up message sent, device configuration is possible
On	Normal operation mode, Encoder in Operational Status



## Transmission Mode

Polled Mode	By a telegram the connected host calls for the current process value. The absolute rotary encoder reads the current position value, calculates eventually set-parameters and sends back the obtained process value by the same identifier
Change of State	The absolute rotary encoder transmits the actual process value. The process value is transmitted when the position changes. This is useful to reduce the bus activity
CYCLIC Mode	The absolute rotary encoder transmits the actual process value event controlled by an internal timer. This is also useful to reduce the bus activity

# **Programmable Parameters**

Operating Parameters	As operating parameters the code sequence (complement) can be programmed. This parameter determines the counting direction, in which the output code increases or decreases
Resolution (pos./turn)	The parameter resolution per revolution is used to program the desired number of steps per revolution. Value between 1 and 8 192 can be programmed
Total Resolution "Max-RANGE"	This parameter is used to program the desired number of measuring units over the total measuring range. This value may not exceed the total resolution of the absolute rotary encoder. If the encoder is used in a continuous measuring application, certain rules for the setting of this parameter must be followed. These rules are outlined in the manual
Preset Value	The preset value is the desired position value, which should be reached at a certain physical position of the axis. The position value is set to the desired process value by the parameter pre-set


## Installation

The rotary encoder is connected by three cables. The power supply is achieved with a two-wire connection cable through one PG 9. Each one of the twisted-pair and shielded bus lines are guided in and out through two PG 9 on the right side (as seen on clamps).

# Configuration


The setting of the node number is achieved by 2 turn-switches in the connection cap. Possible addresses lie between 0 and 63 whereby every address can only be used once. 2 LEDs on the backside of the connection cap show the operating status of the encoder.





# ORDERING REFERENCE

#### Example: MHM5 - D2 B1 B - 12 13 - C10 0 - H3F





### **AGENCY APPROVALS & CERTIFICATIONS**





Page 4

Datasheets provided by Sensata Technologies, Inc., its subsidiaries and/or affiliates ("Sensata") are solely intended to assist third parties ("Buyers") who are developing systems that incorporate Sensata products (also referred to herein as "components"). Buyer understands and agrees that Buyer remains responsible for using its independent analysis, valuation, and judgment in designing Buyer's systems and products. Sensata datasheets have been created using standard laboratory conditions and engineering practices. Sensata has not conducted any testing other than that specifically described in the published documentation for a particular datasheet. Sensata may make corrections, enhancements, improvements, and other changes to its datasheets or components without notice. Buyers are authorized to use Sensata datasheets with the Sensata component(s) identified in each particular datasheet. HOWEVER, NO OTHER LICENSE, EXPRESS OR IMPLIED, BY ESTOPPEL OR OTHERWISE TO ANY OTHER SENSATA INTELLECTUAL PROPERTY RIGHT, AND NO LICENSE TO ANY THIRD PARTY TECHNOLOGY OR INTELLECTUAL PROPERTY RIGHT, IS GRANTED HEREIN. SENSATA DATASHEETS ARE PROVIDED "AS IS". SENSATA MAKES NO WARRANTIES OR REPRESENTATIONS WITH REGARD TO THE DATASHEETS OR USE OF THE DATASHEETS, EXPRESS, IMPLIED, OR STATUTORY, INCLUDING ACCURACY OR COMPLETENESS. SENSATA DISCLAIMS ANY WARRANTY OF TITLE AND ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, QUIET ENJOYMENT, QUIET POSSESSION, AND NON-INFRINGEMENT OF ANY THIRD PARTY INTELLECTUAL PROPERTY RIGHTS WITH REGARD TO SENSATA DATASHEETS OR USE THEREOF.

All products are sold subject to Sensata's terms and conditions of sale supplied at www.sensata.com. SENSATA ASSUMES NO LIABILITY FOR APPLICATIONS ASSISTANCE OR THE DESIGN OF BUYERS' PRODUCTS. BUYER ACKNOWLEDGES AND AGREES THAT IT IS SOLELY RESPONSIBLE FOR COMPLIANCE WITH ALL LEGAL, REGULATORY, AND SAFETY-RELATED REQUIREMENTS CONCERNING ITS PRODUCTS, AND ANY USE OF SENSATA COMPONENTS IN ITS APPLICATIONS, NOTWITHSTANDING ANY APPLICATIONS-RELATED INFORMATION OR SUPPORT THAT MAY BE PROVIDED BY SENSATA.

Mailing Address: Sensata Technologies, Inc., 529 Pleasant Street, Attleboro, MA 02703, USA

#### **CONTACT US**

#### Americas

+1 (800) 350 2727 sensors@sensata.com **Europe, Middle East & Africa** +33 (3) 88 20 8080 position-info.eu@sensata.com **Asia Pacific** 

sales.isasia@list.sensata.com China +86 (21) 2306 1500 Japan +81 (45) 277 7117 Korea +82 (31) 601 2004 India +91 (80) 67920890 Rest of Asia +886 (2) 27602006 ext 2808